


PGMFI
Grassroots Engine Management




ZEROLIFT
AUTOLAB

Tuning Specialists! Where Reliability & Drivability meet!

Lowest Prices Around! - If we can't beat a price, we will give you a \$50.00 In Store Credit!!!

513.874.2508
www.zerolift.com
AIM: ZeroliftAuto



Library > **WireHarness**


Destinations: [Home](#) | [Library](#) | [Change Log](#) | [Index](#)

Search | Go


A Wire Harness is a term for the connectors and wires that are connected to the ECU. OBD0 , OBD1 and OBD2 all have different connectors and there are different wire setups for different ECUs.

Here are the pinouts of the OBD2 a, OBD2 b, and OBDI (AKA OBDIIa, OBDIIb, OBD1 .. I'm putting in all the keywords so you can find this :) connectors.


* RPT's ODB1 / OBD2A / OBD2B pinout image:



OBDIIa (B16A3)



OBDIIb (D16Y8)



OBD I (B16A2)

[edit: what happened to the factory manual OBD1 Integra ECU connector wiring diagram scans ? ? ? they used to be on P72]

Revision: r1.2 - 22 Jun 2004 - 16:07 GMT - blundar

{ [Edit](#) | [Attach](#) | [History](#) | [More](#) }

Copyright © 2002-present by the contributing authors. All material on this collaboration platform is the property of the contributing authors, and is covered by the [Non-Commercial Share-Alike License](#) unless explicitly stated otherwise.

Ideas, requests, problems regarding the PGMFI Twiki? E-Mail the WikiAdmin

Site Designed By: [Digital Fusion](#) [Need a website?](#)